

# MITSUBISHI

## A1S64TCTT-S1 Temperature Control Module A1S64TCTTBW-S1 Temperature Control Module with Disconnection Detection Function

Mitsubishi General-Purpose Programmable Controller

### User's Manual

(Hardware)

Thank you for purchasing the Mitsubishi general-purpose programmable controller MELSEC-A series. Prior to use, please read this manual thoroughly and familiarize yourself with the product.



|           |                   |
|-----------|-------------------|
| Type      | A1S64TCS1-U-E-H/W |
| Type Code | 13J890            |

IB(NA)-66746-B(9808)MEE

© 1996 MITSUBISHI ELECTRIC CORPORATION

#### ● SAFETY PRECAUTIONS ●

(Please read these precautions prior to use.)

When using Mitsubishi equipment, thoroughly read this manual and the associated manuals introduced in this manual. Also, pay careful attention to safety and handle the module properly.

These precautions apply only to Mitsubishi equipment. Refer to the CPU module user's manual for a description of the PC system safety precautions.

These ● SAFETY PRECAUTIONS ● classify the safety precautions into two categories: "DANGER" and "CAUTION".

#### **⚠ DANGER**

Procedures which may lead to a dangerous condition and cause death or serious injury if not carried out properly.

#### **⚠ CAUTION**

Procedures which may lead to a dangerous condition and cause superficial to medium injury, or physical damage only, if not carried out properly.

Depending on circumstances, procedures indicated by **⚠ CAUTION** may also be linked to serious results.

In any case, it is important to follow the directions for usage.

Store this manual in a safe place so that you can take it out and read it whenever necessary. Always forward it to the end user.

#### 【Design precautions】

##### **⚠ DANGER**

- Configure a safety circuit external to the PC, so that the entire system operates safely even if there is an external power error or if the PC is malfunctioning.

##### **⚠ CAUTION**

- Do not bundle, or near the control cables and communication cables with the main circuit and power cables. Keep them at least 100mm (3.94inch) away from such cables. Noise may cause erroneous operation.

#### 【Installation precautions】

##### **⚠ CAUTION**

- Use the PC in the environment given in the general specifications of this manual. Using the PC outside the range of the general specifications may result in electric shock, fire or malfunctioning, or may damage or degrade the module.
- Insert the tabs at the bottom of the module into the mounting holes in the base module before installing the module, and after tightening the module fixing screws with specified torque. If the connector is not properly installed and tightened, it may result in malfunctioning, failure or cause the module to fall out. Tightening the screws too far may cause damage to the screw and/or the module, resulting in fall out, short circuit or malfunctions.
- Do not directly touch the module's conductive parts or electronic components. Doing so could cause malfunction or failure in the module.
- Insert the wire breakage detection connector installation screw into the mounting holes in the module, and after tightening the connector installation screw with specified torque. If the connector is not properly installed and tightened, it may result in malfunction, failure, or fall out.

#### 【Wiring precautions】

##### **⚠ CAUTION**

- Be sure to ground the shield wire with a special PC ground of Type III or above. Not doing so could result in malfunction.
- When wiring in the PC, be sure that it is done correctly by checking the product's rated voltage and the terminal layout. Connecting a power supply that is different from the rating or incorrectly wiring the product could result in fire or failure.
- Tighten the terminal screws with specified torque. Loose terminal screws may cause a short circuit, fire, or malfunction. Tightening the terminal screws too far may cause damage to the screw and/or the module, resulting in fall out, short circuit, or malfunctions.
- Be sure that cuttings, wire chips, or other foreign matter do not enter the module. Foreign matter may start a fire or cause failure or malfunctions.
- Be sure to fix communication cables and power cables leading from the module by placing them in the duct or clamping them. Cables not placed in the duct or without clamping may hang or shift, allowing them to be accidentally pulled, which may result in a module malfunction and cable damage.
- When detaching the communication cable from the module, do not pull the cable portion. For cables with connectors, hold the connector at the junction to the module, then detach it. For cables without connectors, first loosen the screw at the junction, then detach the cable. Pulling the cable portion while it is connected to the module may cause a malfunction or damage to the module and cable.

#### 【Starting and maintenance precautions】

##### **⚠ DANGER**

- Do not touch the terminal while the power is on. It may cause malfunction.
- Make sure to switch all phases of the external power supply off before cleaning or re-tightening the terminal screws. If you do not switch off the external power supply, it will cause electric shock. If the screws are loose, it may result in fallout, short circuits or malfunction. Tightening the screws too far may cause damage to the screw and/or the module, resulting in fall out, short circuit, or malfunctions.

##### **⚠ CAUTION**

- Never disassemble or modify the module. This may cause failure, malfunctioning, injury and/or fire.
- Make sure to switch all phases of the external power supply off before mounting or removing the module. If you do not switch off the external power supply, it will cause failure or malfunction of the module.

#### 【Disposal precaution】

##### **⚠ CAUTION**

- When disposing of this product, handle it as an industrial waste.

## About the Manuals

The following product manuals are available. Please use this table as a reference to request the appropriate manual as necessary.

### Detailed manual

| Manual name  | Manual No (Model Code) |
|--|------------------------|
| A1S64TCTT-S1 Temperature Control Module<br>A1S64TCTTBW-S1 Temperature Control Module with Disconnection Detection Function<br>User's Manual (Detailed edition) | IB-66747<br>(13J891)   |

Please read A1S64TCTT-S1 Temperature Control Module A1S64TCTTBW-S1 Temperature Control Module with Disconnection Detection Function User's Manual (Detailed edition) when using this unit.

## 1. General Description

This user's manual describes the specification, name of each part, wiring, etc of the A1S64TCTT-S1 Temperature Control Module (Hereafter abbreviated as A1S64TCTT-S1) A1S64TCTTBW-S1 Temperature Control Module with Disconnection Detection Function (Hereafter abbreviated as A1S64TCTTBW-S1)

A1S64TCTT-S1 and A1S64TCTTBW-S1 abbreviated as A1S64TC

After unpacking, confirm that there is the following products

| Item           | A1S64TCTT-S1<br>Main body | A1S64TCTTBW-S1<br>Main body |
|----------------|---------------------------|-----------------------------|
| A1S64TCTT-S1   | 1                         | —                           |
| A1S64TCTTBW-S1 | —                         | 1                           |

## 2. Performance Specification

The A1S64TC performance specification is indicated in Table 2 1

Table 2 1 A1S64TC performance specification

| Item   | Specification  |  |
|--|--|--|
|  | A1S64TCTT-S1   | A1S64TCTTBW-S1                         |
| Control output value                           | Transistor output  |  |
| Temperature input points                       | 4-channel/module   |  |
| Supported thermocouple                         | Refer to Table 2.2   |  |
| Specification accuracy                         | Ambient temperature 23°C±5°C<br>(Setting value±0.3%) ±1 digit<br>Ambient temperature 0°C to 55°C<br>(Setting value±0.7%) ±1 digit  |  |
| Cool contact temperature compensation accuracy | Within±1.0°C (0 to 55°C)<br>Within±2.0°C when the input temperature is in the range -100 to 150°C, within±3.0°C when -150 to 250°C |  |
| Sampling cycle                                 | 0.5s/4-channel   |  |
| Control output cycle                           | 1 to 100 Ω   |  |
| Effects of the external resistance             | 0.35 μV/Ω  |  |
| Input impedance                                | 1M Ω or more   |  |
| Input filter                                   | 1 to 100S (0. input filter off)  |  |
| Sensor compensation value setting              | -5.00 to 5.00%   |  |
| Operation when there is an input disconnection | Upscale processing   |  |
| Temperature control method                     | PID ON/OFF pulse or 2-position control   |  |
| PID constant range                             | PID constant setting   | Auto-tuning setting is possible        |
|  | Proportional region (P)  | 0.0 to 100.0% (0.0 2-position control) |
|  | Integral time (I)  | 1 to 3600s                             |
|  | Derivative time (D)  | 1 to 3600s (Set 0 for PI control)      |
| Set value range                                | Within the temperature range set with the thermocouple to be used.   |  |
| Blind sector setting range                     | 0.1 to 10.0%   |  |
| Transistor output                              | Output signal  | ON/OFF Pulse                           |
|  | Rated load voltage   | 10.2 to 30VDC                          |
|  | Maximum load current   | 0.1A/point<br>0.4A/common              |
|  | Maximum inrush current   | 0.4A 10ms                              |
|  | Maximum voltage drop when ON   | 0.1VDC (TYP) 0.1A<br>2.5VDC (MAX) 0.1A |
| Response time                                  | OFF→ON Less than 2ms<br>ON→OFF Less than 2ms (resistor load)   |  |

Table 2 1 A1S64TC performance specification (continued)

| Item                               | Specification  |   |
|------------------------------------|--|---|
|                                    | A1S64TCTT-S1   | A1S64TCTTBW-S1  |
| Insulation method                  | Between the thermocouple input and grounding<br>Transformer insulation<br>Between the thermocouple input and channel<br>Transformer insulation |   |
| Heater disconnection specification | Current sensor   | —<br>URD manufactured current sensor*<br>CTL-12-S36-8<br>(0.0 to 100.0A)<br>CTL-6-P<br>(0.00 to 20.00A) |
|                                    | Input method   | Multiplexor method A/D conversion   |
|                                    | Alert delay count  | 3 to 255  |
| I/O occupied points                | 32 points  |   |
| Connection terminal                | 20 points terminal block   |   |
| Supported cable size               | 0.75 to 1.5mm  |   |
| Supported solderless terminal      | R1.25-3, 1.25-YS3, RAV1.25-3, V1.25-YS3A   |   |
| Internal consumed current (mA)     | 330  | 420   |
| Weight (kg) [lb]                   | 0.27[0.59]   | 0.3[0.66]   |
| External dimensions (mm) [inch]    | 130[5.12](H) × 34.5[1.36](w) × 93.6[3.69](D)   |   |

For the noise resistance, dielectric withstand voltage, and insulation resistance for the PC system which uses this module, refer to the power module specification found in the CPU Module User's Manual

\* Only the URD International, Ltd current sensor can be used  
Sales channels for current sensors manufactures by URD International Ltd are listed as follows


|           |  |             |  |
|-----------|--|-------------|--|
| U S A     | URD AMERICA Inc<br>Tel 714-831-0111                        | Hong Kong   | GRANDFIT TRADING LIMITED<br>Tel 2782-0254        |
| Brazil    | DP GENCO INDUSTRIA E<br>COMERCIO LTDA<br>Tel 011-5584-0959 | South Korea | JOYANG TRADING CO<br>Tel 02-831-9596             |
| Germany   | ALLIED ELECTRONICS<br>GmbH<br>Tel 0221-497-3084            |             | TWINKLE STAR<br>ELECTRIC CO<br>Tel 02-269-9758   |
| France    | DILTRONIC S A<br>Tel 1-34-51-33-00                         | India       | AMTECH<br>ELECTRONICS PVT LTD<br>Tel 02712-25324 |
| Singapore | LEE LABORATORIES PTE LTD<br>Tel 297-2700                   |             |  |

Table 2 2 The types of supported thermocouples and the measured temperature range

| Thermocouple | °C  |                 | °F                                  |                 |
|--------------|---|-----------------|-------------------------------------|-----------------|
|              | Measured temperature range                                      | Data resolution | Measured temperature range          | Data resolution |
| R            | 0 to 1700   | 1               | 0 to 3000                           | 1               |
| K            | 0 to 500<br>0 to 800<br>0 to 1300                               | 1               | 0 to 1000<br>0 to 2400              | 1               |
|              | -200.0 to 400.0<br>0.0 to 400.0<br>0.0 to 500.0<br>0.0 to 800.0 | 0.1             | 0.0 to 1000.0                       | 0.1             |
|              | 0 to 500<br>0 to 800<br>0 to 1200                               | 1               | 0 to 1000<br>0 to 1600<br>0 to 2100 | 1               |
| J            | 0 to 500<br>0 to 800<br>0 to 1200                               | 1               | 0 to 1000<br>0 to 1600<br>0 to 2100 | 1               |
|              | 0.0 to 400.0<br>0.0 to 500.0<br>0.0 to 800.0                    | 0.1             | 0.0 to 1000.0                       | 0.1             |
|              | -200 to 400<br>-200 to 200<br>0 to 200<br>0 to 400              | 1               | 0 to 700<br>-300 to 400             | 1               |
| T            | -200.0 to 400.0<br>0.0 to 400.0                                 | 0.1             | 0.0 to 700.0                        | 0.1             |
|              | 0 to 1700   | 1               | 0 to 3000                           | 1               |
| B            | 0 to 1800   | 1               | 0 to 3000                           | 1               |
| E            | 0 to 400<br>0 to 1000   | 1               | 0 to 1800                           | 1               |
|              | 0.0 to 700.0  | 0.1             | —                                   | —               |
| N            | 0 to 1300   | 1               | 0 to 2300                           | 1               |
| U            | 0 to 400<br>-200 to 200   | 1               | 0 to 700<br>-300 to 400             | 1               |
|              | 0.0 to 600.0  | 0.1             | —                                   | —               |
| L            | 0 to 400<br>0 to 900  | 1               | 0 to 800<br>0 to 1600               | 1               |
|              | 0.0 to 400.0<br>0.0 to 900.0                                    | 0.1             | —                                   | —               |
| PL II        | 0 to 1200   | 1               | 0 to 2300                           | 1               |
| W5Re/W26Re   | 0 to 2300   | 1               | 0 to 3000                           | 1               |



For the general specifications, refer to the User's Manual for the PC CPU used

### 3. Name of Each Part



A1S64TCTT-S1 LED

A1S64TCTTBW-S1 LED



| Number | Name   | Description  |
|--------|--|--|
| ①      | LED  | <p><b>RUN</b> A1S64TC operation status display</p> <p>ON Normal operation</p> <p>Flashing (2 sec ON, 2 sec OFF) When write data error occurs</p> <p>Flashing (1 sec ON, 1 sec OFF) Hardware error</p> <p>OFF. 5V power OFF</p>   |
|        | OUT  | <p>Transistor output status display</p> <p>ON Transistor output ON</p> <p>OFF Transistor output OFF</p>  |
|        | ALM  | <p>Alert alarm status display</p> <p>ON The alert alarm is turned ON</p> <p>LAB error occurred</p> <p>Flashing The measured temperature range is exceeded</p> <p>The thermocouple is not connected</p> <p>The thermocouple cable is not connected</p> <p>OFF The alert alarm is OFF.</p> |
|        | BR W   | <p>Heater disconnection detection status display</p> <p>ON The heater disconnection is detected</p> <p>OFF The heater disconnection has not been detected.</p>   |
| ②      | Cool contact temperature compensation resistor | Shipped pre-installed to the terminal block  |
| ③      | Disconnection detection connector              | <p>Connector to the current sensor</p> <p>Wire breakage detection connector installation screw</p> <p>Cable fixing screws</p> <p>BW1(For CH1)</p> <p>BW2(For CH2)</p> <p>BW3(For CH3)</p> <p>BW4(For CH4)</p>  |

### 4. Loading and Installation

Precautions when handling the A1S64TC and installation environment are explained

For details of implementing and setting up this unit, please refer to the User's Manual for the PC CPU used

#### 4.1 Handling Instructions

- 1) The module case is made of plastic. Be sure not to drop it or subject it to strong vibration.
- 2) Do not remove the module printed circuit boards from the case. It may cause trouble.
- 3) When connecting the wiring, do not allow wire cuttings or other foreign matter to enter from the top of the module. Remove any foreign matter from the module.
- 4) Tighten the module installation screws within the following tightening torque range.

| Screw position  | Tightening torque range                                       |
|---|---|
| Module installation screw (M4 screw)                                | 78 to 118N · cm (8 to 12kgf · cm)<br>[6.9 to 10.4 lb · inch]  |
| Terminal block terminal screw (M3.5 screw)                          | 59 to 88N · cm (6 to 9kgf · cm)<br>[5.2 to 7.8 lb · inch]     |
| Terminal block installation screw (M4 screw)                        | 78 to 118N · cm (8 to 12kgf · cm)<br>[6.9 to 10.4 lb · inch]  |
| Wire breakage detection connector installation screw *(M2.6 screws) | 15 to 30N · cm (1.5 to 3 kgf · cm)<br>[1.3 to 2.7 lb · inch]  |
| Cable fixing screw *(M2 screws)                                     | 11 to 14N · cm (1.1 to 1.4kgf · cm)<br>[1.0 to 1.2 lb · inch] |

\* Use only for A1S64TCTTBW-S1

#### 4.2 Installations Environment

Never install the AnS series PC in the following environments

- 1) Locations where the ambient temperature is outside the range of 0 to 55°C
- 2) Locations where the ambient humidity is outside the range of 10 to 90%RH
- 3) Locations where dew condensation takes place due to sudden temperature changes
- 4) Locations where there are corrosive and/or combustible gasses
- 5) Locations where there is a high level of conductive power (such as dust and iron filings, oil mist, salt, and organic solvents)
- 6) Locations exposed to the direct rays of the sun
- 7) Locations where strong power and magnetic fields are generated
- 8) Locations where vibration and shock are directly transmitted to the main module

### 5. Wiring

The precaution when wiring and the module connection example are shown below

#### 5.1 Precaution when wiring


In order to have the best result from the A1S64TC functions and to make the system highly reliable, an external cabling with low noise effects are necessary

The external wiring precautions are shown below

- 1) Use separate cables for the alternating current and A1S64TC external input signals to avoid A/C surges and induction effects
  - 2) Do not bunch the cables with the main circuit, high-voltage cable or load cables from other than PC, or install them close to each other
- Install the thermocouple at least 10 cm away from the main circuit line or alternating current control circuit
- Install the cables far apart from high-frequency circuits, such as the high-voltage cable and inverter load main circuit, as much as possible
- This increases the noises, surges, and induction
- 3) Perform a one-point grounding for the shielded line and shields of the seal and cable at the PC. However, there may be cases when grounding should be performed externally depending on the noise condition


## 5.2 Module wiring example

### 1) A1S64TCTT-S1




\* Always use the shielded compensating conductor for the cable

### 2) A1S64TCTTBW-S1




\*1 Always use the shielded compensating conductor for the cable

\*2 Refer to the following for the connection of the disconnection detector connector




## 6. External Dimensions

### 1) A1S64TCTT-S1



### 2) A1S64TCTTBW-S1



Unit mm(inch)

|                          |  |
|--------------------------|--|
| The United States        | Mitsubishi Electronics America, Inc. (Industrial Automation Division)<br>800 Biemann Court Mt. Prospect IL 60056<br>Phone : (708) 298-9223               |
| Canada                   | Mitsubishi Electric Sales Canada Inc (Industrial Automation Division)<br>4299 14th Avenue, Markham, Ontario L3R 0J2<br>Phone : (416) 475-7728            |
| United Kingdom           | Mitsubishi Electric UK Ltd, (Industrial Sales Division)<br>Travellers Lane Hatfield Herts, AL10 8XB<br>Phone : (0707) 276100                             |
| Germany                  | Mitsubishi Electric Europe GmbH (Industrial Automation Division)<br>Gothaer Strasse 8 Postfach 1548 D-4030 Ratingen 1<br>Phone : (02102) 4860            |
| Taiwan                   | Settsuyo Enterprise Co., Ltd<br>(106) 11th Fl Chung-Ling Bldg, 363 Sec 2 Fu-Hsing S Rd, Taipei<br>Taiwan R O C<br>Phone : (02) 732 0161                  |
| Hongkong (& China)       | Ryoden International Ltd, (Industrial & Electrical Controls Division)<br>10/F, Manulife Tower 169 Electric Rd, North Point, Hong Kong<br>Phone : 8878870 |
| Singapore (& Malaysia)   | MELCO Sales Singapore Pte Ltd (Industrial Division)<br>307 Alexandra Rd #05-01/02, Mitsubishi Electric Bldg, Singapore 0315<br>Phone : 4732308           |
| Thailand                 | F A Tech Co., Ltd,<br>1138/33-34 Rama 3 Rd, Yannawa Bangkok 10120<br>Phone : (02) 295 2861 4   |
| Australia                | Mitsubishi Electric Australia Pty Ltd (Industrial Controls Division)<br>348 Victoria Rd Rydalm ere N S W 2116<br>Phone : (02) 684 7200                   |
| Republic of South Africa | M S A Manufacturing (Pty) Ltd (Factory Automation Division)<br>P O Box 39733, Bramley Johannesburg 2018<br>Phone : (011) 444-8080                        |

**MITSUBISHI ELECTRIC CORPORATION**  
HEAD OFFICE: 2-1-1 HAMA KU, TOKYO 100-8555 TEL: 81-3-3441-5000 FAX: 81-3-3441-5001  
MAGUYA WORKS: 1-1-1 YAMA KU, MAGUYA 519-0292 TEL: 81-73-441-5000 FAX: 81-73-441-5001

When exported from Japan, this manual does not require application to the Ministry of International Trade and Industry for service transaction permission

Specifications subject to change without notice  
Printed in Japan on recycled paper